


V4.1

2024.10

Z-9B

User Manual



Using this Manual – Legend



Important



Tips



Explanation

Revision History

Date	Document Version
2024.03.11	V4.0

Date	Document Version
2024.10.15	V4.1

Caution

1. The Z-9B equipped with a laser lighting module, which is a Class 3B invisible laser. DO NOT exposure eyes to the beam within 12 meters or observe the beam by any optical instrument. DO NOT place any inflammable within 20 centimeters in front of the lighting module.
2. When not in use, store the Z-9B in the package box. The recommended storage environment is a relative humidity less than 40% at a temperature of $20\pm5^{\circ}\text{C}$. If the lenses fog up. The water vapor will usually dissipate after turning on the device for a while.
3. Do not expose the thermal camera lens to a strong energy source such as sun, lava or laser beam. The temperature of the observation target should not exceed 600°C , otherwise it will cause permanent damage.
4. Do not place the product under direct sunlight, in areas with poor ventilation, or near a heat source such as a heater.
5. Do not frequently power on/off the product. After it is turned off, wait at least 30 seconds before turning back on, otherwise the product life will be affected.
6. Make sure the pod port and pod surface are free from any liquid before installation.
7. Make sure the pod is securely installed onto the aircraft, the microSD card slot cover is clean and firmly in place.
8. Make sure the pod surface is dry before opening the microSD card slot cover.
9. Do not plug or unplug the microSD card during use.
10. Do not touch the surface of the camera lenses and keep it away from hard objects. As doing so may lead to blurred images and affect the imaging quality.
11. Clean the surface of the camera lenses with a soft, dry, clean cloth. Do not use alkaline detergents.
12. When not receiving valid carrier INS data, the yaw shaft of the pod will drift about 15 degrees per hour because of the earth rotation. To make sure the pod attitude corrects, it is necessary to transmit valid carrier INS data, usually the GNSS should be positioning.
13. When its damping platform tilted over 45° , the pod will trigger protection mode and return to its neutral position. (except in FPV mode)

Catalog

Introduction	1
Synopsis	1
Characteristics	2
Overview	3
Quick-Release Module Fuselage Section dimensions	4
Port Definition	5
Installation	6
Configuration & Upgrading	7
AICore Upgrading	7
GCU Upgrading	8
Gimbal Upgrading	8
Real-time Video Playing	8
Appendix 1 Specifications	9
Appendix 2 SEI Data Structure	13
Appendix 3 MAVLink Configuration	14
ArduPilot	14
PX4	15
Appendix 4 MAVlink Communication Process	16
Appendix 5 Wiring Diagram of Connecting to Open Source Autopilot	17

Introduction

Synopsis

The Z-9B equips with a high accuracy 3-axis nonorthogonal gimbal, an 120x hybrid zoom camera and a long-wave thermal camera, which can provide visual and infrared images simultaneously. Thanks to the laser range finder, the Z-9B can provide the location of a target and the distance to it that improves working efficiency. Turning on the laser lighting module, the Z-9B can provide a clear image even in complete dark environments.


The Z-9B have AI multi-object detection and tracking function. The gimbal camera can intelligently identify the persons and vehicles in the image, and constantly track one of them.

The Z-9B can be mounted tool-lessly onto multiple carriers, whether downward or upward. With the GCU and the Dragonfly software, user can watch the image from the camera and control the pod real-timely on a computer.

Characteristics


- Features AI multi-object detection and tracking, which can constantly track one of the persons and vehicles intelligently identified in the image.
- Carries an 120x hybrid zoom camera, a thermal camera and a laser range finder.
- Laser lighting module ensures the cameras getting a clear image even in complete darkness.
- 3-axis orthogonal mechanical stabilized structure, is able to spin continually around its yaw axis
- Built-in GCU module makes the product more integrated.
- Supports network, UART and S.BUS control. Supports both private protocol and MAVlink protocol.
- Thanks to the Dual-IMU complementary algorithms with IMU temperature control and carrier AHRS fusion, the Z-9B provides a stabilization accuracy at $\pm 0.01^\circ$.
- Can be mounted onto multiple carriers, whether downward or upward.
- With the Dragonfly software, user can watch the image and control the gimba without protocol ducking.
- Photos and videos can be downloaded online through the "Gallery" function of the Dragonfly software.
- With the customized QGC software, all the functions of the pod can be achieved in conjunction with an open source autopilot.
- Screen supports overlaying OSD information such as latitude, longitude and altitude. Image supports shooting point coordinate EXIF save. Video stream supports SEI stacking.
- 20~53 VDC wide voltage input.

Overview




- | | |
|--------------------------|---------------------|
| 1. Upgrade Port | 2. Damping Platform |
| 3. Laser Range Finder | 4. Thermal Camera |
| 5. Laser Lighting module | 6. Zoom Camera |
| 7. MicroSD Card Slot | |

Quick-Release Module Fuselage Section dimensions



⚠ Use screws of proper length to fix the Quick-Release module. Too short screws short may cause the fixation unsecure, and too long screws may intervene with the device.

Port Definition



1. POWER


2. ETH

3. S.BUS/UART


Port	Pin	Definition	Description
POWER	1	GND	Operating Voltage: 14~52V DC
	2	GND	
	3	NC	
	4	Vin	
	5	Vin	
ETH	1	NC	GCU configuring; Private protocol control; HD image Output
	2	NC	
	3	T+	
	4	T-	
	5	R+	
S.BUS	6	R-	Support S.BUS1 standard such as FASST and SFHSS and S.BUS2 standard such as FASSTest
	1	GND	
	2	NC	
UART	3	S.BUS	GCU configuring; Private protocol control; MAVlink protocol control
	1	GND	
	2	UART_Rx	
	3	UART_Tx	

Installation



Turn the load locking knob to the unlocked position, and push the load at a constant speed along the quick disconnecting guide rail until the quick disconnecting component makes a slight "click" sound to turn the knob to the locked position.



 **Make sure the load is installed and locked after installation!**



Turn the load locking knob to the release position. Press and hold the load release button on the other side and remove the load.



-  During use or storage, cover the SD card protection cover to prevent liquid or dust from entering.
-  The pod heats while operating. Please ensure the device good cooling.
-  Do not hard-connect the pod to the carrier , and make sure that the pod does not come into contact with the carrier during use.

Configuration & Upgrading

-  Ensure the gimbal and the GCU have both been upgraded to the latest firmware before use. Otherwise, usage may be affected.
-  Ensure the driver of the config module is installed on the computer before configuration or upgrading.
-  Before configuration, the computer should be set to a static IP address, which is in the same network segment with the GCU and the camera (without IP address conflicts). The default IP address of the GCU and the camera are 192.168.144.121 and 192.168.144.108, and an interior reserved IP address is 192.168.144.199.
-  Do not power off the device while upgrading. Restart the device once the upgrading is complete.

1. Connect the computer and ETH port with the Network Conversion Module. Power on the devices.
2. Run the Dragonfly display and control software to confirm that it is connected to the pod. Open the settings page.
3. When the settings are complete, click "Save".
4. Restart the pod to enable the configurations to take effect.


 For instructions on Net Settings, CAMERA, S.BUS Setting, Calibration, Carrier, and Advance, please refer to the 《Dragonfly Quick Start Guide》 - Ribbon - Settings, or visit the www.allxianfei.com to get information in the Video Center.

AlCore Upgrading

1. Connect the computer and ETH port with the Network Conversion Module. Power on the device.
2. Run AlCore Upgrade Tool software. Input current camera IP address and click "Connect".
3. Drag the firmware file. Click "Firmware Download" and wait for the download completing.
4. Restart the pod to enable the upgrading to take effect.

GCU Upgrading

1. Connect the computer and UART port with the J1.25 Config Module.
2. Run FreeFlightIAP software. Choose the COM port corresponding to the config module.
3. Click "browse", choose the firmware file, click "download" and wait for the upgrading complete.




Visit the www.allxianfei.com for more information in the Video Center.

Gimbal Upgrading

1. Connect the computer and the upgrade port with the J1.25 Config Module. Power on the device.
2. Run GimbalConfig software. Choose the COM port corresponding to the config module. Click "Open Firmware", choose the firmware file, click "Start Upgrade" and wait for the upgrading complete.



For some brands of dual Type-C cables, there may be cases where the computer cannot recognize the Config Module. Please try replacing it with a Type-A to Type-C cable.



Visit the www.allxianfei.com for more information in the Video Center.

Real-time Video Playing

Example as camera IP address 192.168.144.108:

Stream address: <rtsp://192.168.144.108>

Appendix 1 Specifications

General			
Product Name	Z-9B		
Dimensions	173 x 144 x 206mm		
Weight	1158g		
Operating Voltage	20 ~ 53 VDC		
Power	21.4W (AVG, ranging & light off) / 50.4W (Stall, ranging & light on)		
Mounting	Downward / Upward		
Target Positioning Accuracy ^[1]	Horizontal Error: 1.8m	@	Horizontal Distance: 105m
	Vertical Error: 0.7m		Relative Height: 75m
	Horizontal Error: 17.4m	@	Horizontal Distance: 513m
	Vertical Error: 6.7m		Relative Height: 119m
	Horizontal Error: 33.8m	@	Horizontal Distance: 1003m
	Vertical Error: 13.7m		Relative Height: 246m
Gimbal			
Gimbal Type	3-axis orthogonal Mechanical Stabilization		
Angular Accuracy	±0.01°		
Controllable Range	Pitch: -120°~ 55° , Roll: ±40° , Yaw: ±360° constantly		
Max Controllable Speed	±200° /s		
Zoom Camera			
Image Sensor	1/2.8-inch CMOS, Effective Pixels: 4.09M		
Lens	Actual Focal Length: 4.7~141mm (Equivalent focal length: 27.9~837mm)		
	Aperture: f/1.5~f/4.0		
	HFOV: 59.5°~ 2.2°		
	VFOV: 35.8°~ 1.2°		
	DFOV: 66.6°~ 2.5°		
Resolution	2688(H) x 1520(V)		
Pixel Size	2.0μm(H) x 2.0μm(V)		
Optical Zoom Rate	30x		
Equivalent Digital Zoom Rate	4x		

Object Detection Distance	EN62676-4:2015	Person ^[2] : 3283m Light vehicle ^[3] : 4315m Large vehicle ^[4] : 9192m
	Johnson Criteria	Person: 37500m Light vehicle: 115000m Large vehicle: 245000m
Object Identification Distance	EN62676-4:2015	Person: 657m Light vehicle: 863m Large vehicle: 1838m
	Johnson Criteria	Person: 9375m Light vehicle: 28750m Large vehicle: 61250m
Object Verification Distance	EN62676-4:2015	Person: 328m Light vehicle: 432m Large vehicle: 919m
	Johnson Criteria	Person: 4688m Light vehicle: 14375m Large vehicle: 30625m
Thermal Camera		
Thermal Sensor	Uncooled VOx Microbolometer	
Lens	Focal Length: 25mm (Equivalent focal length: 93.2mm) Aperture: f/1.0 HFOV: 17.5° VFOV: 14.0° DFOV: 22.3°	
Resolution	640(H) x 512(V)	
Pixel Size	12μm(H) x 12μm(V)	
Equivalent Digital Zoom Rate	8x	
Spectral Band	8~14μm	
Sensitivity (NETD)	<50mk@F1.0@25°C	
Object Detection Distance	Johnson Criteria	Person: 1042m Light vehicle: 3194m Large vehicle: 6806m
Object Identification Distance		Person: 260m Light vehicle: 799m Large vehicle: 1701m
Object Verification Distance		Person: 130m Light vehicle: 399m Large vehicle: 851m

Temperature Measurement	Optional (Thermometry Type)
Temperature Measurement Method	Spot Measurement, Area Measurement
Temperature Measurement Range	High Gain: -20° C~150° C Low Gain: 0° C~550° C
Temperature Alert	High-temp Alert, Low-temp Alert
Sun Burn Protection	Supported ^[5]
Palette	White Hot, Black Hot, Tint, Fulgurite, Iron Red, Hot Iron, Medical, Arctic, Rainbow 1, Rainbow 2
Laser Range Finder	
Wavelength	905nm
Max Laser Power	1mW
Beam Angle	2.5mrad
Beam Diameter	0.25m@100m
Laser Safety	Class 1M (IEC 60825-1:2014)
Measurement Accuracy	±0.3m (≤ 300m) / ±1.0m (>300m)
Measurement Range	5-2000m (φ12m vertical surface with 20% reflectivity)
Laser Lighting Module	
Wavelength	850±10nm
Laser Power	0.8W x2
Beam Angle	8° +30°
Beam Diameter	14m+54m@100m
Effective Illumination Distance	≤ 200m
Laser Safety	Class 3B (IEC 60825-1:2014)
AI Multi-object Detection & Tracking	
Object Identification Size	≥ 30x20 px
Object Identification Rate	≥ 85%
Object Identification Quantity	≤ 50
Target Tracking Size	16x16~256x256 px
Tracking Deviation Refresh Rate	30Hz
Tracking Deviation Output Delay	≤ 60ms
Target Pixel Error	≤ ±1 px
Tracking Speed	>24 px / frame
Target Memory Time	>5s

Image & Video	
Image Format	JPEG
Maximum Image Resolution	1920 x 1080
EXIF	Shooting point coordinate
Video Format	MP4
Maximum Video Resolution	Stream: 1920 x 1080 @25fps Recording: 1920 x 1080 @30fps
Stream Encode Format	H.264, H.265
Stream Network Protocol	RTSP
Storage	
Supported SD Cards	Supports a U3/V30 or above MicroSD card with a capacity of up to 256GB
Environment	
Operating Temperature	-20°C ~ 50°C
Storage Temperature	-40°C ~ 60°C
Operating Humidity	≤ 85%RH (Non-condensing)

- [1] Measured by pod mounted on a dual antenna RTK positioned multicopter drone to a known coordinate point. The target positioning accuracy is influenced by carrier's positioning and orientation accuracy, angle between the direction of pod mounted and the heading of carrier, slant range, gradient of measurement line and air quality. The data is for reference only.
- [2] Reference dimension of person: 1.8x0.5m. Critical dimension under Johnson criteria is 0.75m.
- [3] Reference dimension of light vehicle: 4.2x1.8m. Critical dimension under Johnson criteria is 2.3m.
- [4] Reference dimension of large vehicle: 6.0x4.0m. Critical dimension under Johnson criteria is 4.9m.
- [5] Do not expose the thermal camera lens to a strong energy source such as sun, lava or laser beam. The temperature of the observation target should not exceed 600°C, otherwise it will cause permanent damage.

Appendix 2 SEI Data Structure

typedef struct // 64 bytes. Little-endian byte order. Byte alignment

```
{
    uint8_t head[2]; // Header [0xEE, 0x16]
    struct
    {
        uint8_t rng_trig:1; // Ranging trigger flag
        uint8_t pip_state:3; // Pic-in-Pic Statue
                                0-Zoom camera (main)+Thermal camera (sub);
                                1-Thermal camera;
                                2-Thermal camera (main)+ Zoom camera (sub);
                                3-Zoom camera
        uint8_t data_valid:1; //Validity flag of carrier's coordinate, carrier's attitude
                                and camera's attitude
        uint8_t tgt_valid:1; //Validity flag of target's coordinate
        uint8_t reserved:2; // Reserved flag
    } flag;
    int32_t uav_lon; // Longitude of carrier. [-180°, 180°). Resolution 1e-7deg
    int32_t uav_lat; // Latitude of carrier. [-90°, 90°]. Resolution 1e-7deg
    int32_t uav_alt; // Altitude of carrier. Resolution 1mm
    int32_t uav_hgt; // Relative height of carrier. Resolution 1mm
    int16_t uav_phi; // Roll angle of carrier. [-180°, 180°). Resolution 0.01deg
    int16_t uav_the; // Pitch angle of carrier. [-90°, 90°]. Resolution 0.01deg
    uint16_t uav_psi; // Yaw angle of carrier. [0°, 360°). Resolution 0.01deg
    int16_t cam_phi; // Roll angle of camera. [-90°, 90°]. Resolution 0.01deg
    int16_t cam_the; // Pitch angle of camera. [-180°, 180°). Resolution 0.01deg
    uint16_t cam_psi; // Yaw angle of camera. [0°, 360°). Resolution 0.01deg
    uint16_t cam1_zoom; // Zoom rate of zoom camera. Resolution 0.01x
    uint16_t cam2_zoom; // Zoom rate of thermal camera. Resolution 0.01x
    uint16_t rng_dist; // Distance from target. Resolution 0.1m (Invalid, 0)
    uint16_t gnss_week; //GNSS week
    uint32_t gnss_itow; //GNSS microsecond. Resolution 1ms
    int32_t tgt_lon; // Longitude of target. [-180°, 180°). Resolution 1e-7deg (Invalid, 0)
    int32_t tgt_lat; // Latitude of target. [-90°, 90°]. Resolution 1e-7deg (Invalid, 0)
    int32_t tgt_alt; // Altitude of target. Resolution 1mm (Invalid, 0)
    uint16_t cam1_f1x; // Focal length of zoom camera at 1x. Resolution 0.01mm
    uint16_t cam2_f1x; // Focal length of thermal camera at 1x. Resolution 0.01mm
    uint8_t reserved[4]; // Reserved
    uint8_t check_sum; // Checksum
} SdSei_t;
```

Appendix 3 MAVLink Configuration

ArduPilot

SERIAL1	
SERIAL1_BAUD	115
SERIAL1_OPTIONS	1024
SERIAL1_PROTOCOL	2
SR1	
SR1_ADSB	0 Hz
SR1_EXIT_STAT	0 Hz
SR1_EXTRA1	0 Hz
SR1_EXTRA2	0 Hz
SR1_EXTRA3	0 Hz
SR1_PARAMS	0 Hz
SR1_POSITION	0 Hz
SR1_RAW_CTRL	0 Hz
SR1_RAW_SENS	0 Hz
SR1_RC_CHAN	0 Hz
MNT1	
MNT1_TYPE	4 (Gremsy) / 6 (SToRM32 Mavlink)
RC1	
RC1_OPTOPN	213 (MOUNT1_PITCH)
RC2	
RC2_OPTOPN	214 (MOUNT1_YAW)
RC3	
RC3_OPTOPN	163 (MOUNT1_LOCK)
CAM	
CAM_TRIGG_TYPE	3 (Mount)

-  The MNT1_TYPE is recommended as 6. The MNT1_ROLL_MAX, MNT1_ROLL_MIN, MNT1_PITCH_MAX, MNT1_PITCH_MIN, MNT1_YAW_MAX and MNT1_YAW_MIN will be configured automatically depend on data from the GCU. The angle limit should be set manual while the MNT1_TYPE is 4.
-  The RC1~RC3 are just examples, which can be defined according to actual situation.

PX4

MAVLink	
MAV_1_CONFIG	TELEM2
MAV_1_MODE	Custom / Gimbal
MAV_1_RATE	115200 B/s
Serial	
SER_TEL2_BAUD	115200 8N1
Mount	
MNT_MAIN_PITCH	AUX1
MNT_MAIN_YAW	AUX2
MNT_MODE_IN	Auto (RC and Mavlink Gimbal)
MNT_MODE_OUT	MAVLink gimbal protocol v2
Camera Setup	
Trigger mode	Distance based, on command (Survey mode)
Trigger interface	MAVLink (forward via MAV_CMD_IMAGE_START_CAPTURE)

-  The MAV_1_MODE is recommended as Custom.
-  The AUX1 and AUX2 are just examples, which can be defined according to actual situation. It should be configured in RC Map for further application.
-  The trigger mode is just an example, which can be modified according to actual situation.

Appendix 4 MAVlink Communication Process

After receiving HeartBeat from the flight controller, and identifying SYSID and COMPID of the flight controller, GCU will operate as below:

1. GCU actively sends package *MAVLINK_MSG_ID_HEARTBEAT 0* at a frequency of 2Hz.
2. GCU requests following packages in turn at a frequency of 1Hz. The flight controller fills these parameters into package *MAVLINK_MSG_ID_COMMAND_LONG 76* until the request completing.:
MAVLINK_MSG_ID_EKF_STATUS_REPORT 193 (No this package for PX4);
MAVLINK_MSG_ID_GLOBAL_POSITION_INT 33;
MAVLINK_MSG_ID_SCALED_IMU 26;
MAVLINK_MSG_ID_SYSTEM_TIME 2;
MAVLINK_MSG_ID_RC_CHANNELS 65;
MAVLINK_MSG_ID_CAMERA_TRIGGER 112 (No this package for APM);
MAVLINK_MSG_ID_AUTOPILOT_STATE_FOR_GIMBAL_DEVICE 286;
MAVLINK_MSG_ID_GIMBAL_DEVICE_SET_ATTITUDE 284 (No this package for APM);
3. GCU actively sends package *MAVLINK_MSG_ID_GIMBAL_DEVICE_ATTITUDE_STATUS 285* at a frequency of 100 Hz while the packages above being received and the pod being operational.
4. Generally, the flight controller will request package *MAVLINK_MSG_ID_GIMBAL_DEVICE_INFORMATION 283*, which GCU does not send actively.

Appendix 5 Wiring Diagram of Connecting to Open Source Autopilot

